

Challenger Door

Process Control Document

Date :12/19/12

Process Title: Ambulance latch adjustment info

BY: Mike S.

Fig.1

Pin that connects linkage rod to rotary latch can be removed and then turn eyelet to shorten or lengthen linkage which will make the rotary open sooner or later, depending on which way it's turned.



Fig.2

Loosen striker bolt to move it if pin alignment needs to be adjusted.

Loosen hex bolt if striker bolt alignment needs to be adjusted.



Fig.3

One of the green rod clips must be removed if inside paddle portion of latch needs to be removed.



Fig.4

Rotary latch linkage can also be adjusted at paddle portion of latch if you want to, although it is recommended that it be adjusted at rotary area as that is easier to get to most times.

